

Replacing clear meter windows

Advice from our Production Manager Phill Burchell:

Putting in clear meter windows at the time of make is easy. We have had advice that they can easily break when replacing.

After a bit of playing with the meter windows, I worked out that the reason I can get them in easily without breaking is that I put them in before the unit is assembled and can gently press on the middle of the window from the inside, as I put the window in from the outside.

I've found that to replicate that with the unit together, you need to get a nice thin screwdriver or similar and very gently lever the middle of the meter window toward you as you click in the ends. Place the larger, squared end of the window against one side of the opening, place your screwdriver under the middle of the window and gently push the smaller, rounded end of the window into place whilst sliding the screwdriver out at the same time. This will bow the window out toward you, so you only want to use a nice thin screwdriver and be nice and gentle.

Hope this helps!

Phill

Step 1:



Step 2:



Step 3:

